EcoTank Photo L8180

DATASHEET / BROCHURE



EcoTank Photo L8180

Идеально для фотографов и художников: A3+ фотографии лабораторного качества с печатью, копированием и сканированием по низкой цене.

KEY FEATURES

- **6-цветные чернила Epson Claria ET Premium**

  6-цветные чернила Epson Claria ET Premium

- **Сверхэкономичная печать с заправляемыми контейнерами**

  Печать до 2 300 качественных фотографий с одним набором контейнеров[1]

- **Беспроводное подключение для печати из любой точки**

  Поддержка Wi-Fi, Wi-Fi Direct, Ethernet и Apple AirPrint

- **Для работы и творчества**

  Лотки для A4 и фотобумаги, плюс две задние подачи A3+ для плотных носителей

- **Бренд №1 в мире среди СНПЧ-принтеров***

  Продано более 100 млн принтеров EcoTank по всему миру*

EPSON®

PRODUCT SPECIFICATIONS

TECHNOLOGY	
Printing Method	6-colour inkjet printer
Minimum Droplet Size	1.9 pl, With Variable-Sized Droplet Technology
Ink Technology	Пигментный чёрный и цветные чернила на красителях
Printing Resolution	5760 x 1440 DPI
PRINT	
Printing Speed ISO/IEC 24734	16 Pages/min Monochrome, 12 Pages/min Colour
For detailed information on printing speeds please visit http://www.epson.eu/testing.	
SCAN	
Scanner Type	Контактный датчик изображения (CIS)
PAPER / MEDIA HANDLING	
Paper Formats	DIN A3+, A3 (29,7x42, см) , A4 (21,x29,7 см) , A5 (14,8x21, см) , A6 (1,5x14,8 см) , B5, B6, C6 (Envelope), DL (Envelope), No. 1 (Envelope), Letter, 1 x 15 cm, 13 x 18 см, 1 x 148 mm, B4, Legal, Executive
Duplex	Yes (A4, plain paper)
Print Margin	0 mm top, 0 mm right, 0 mm bottom, 0 mm left (Wherever margin is defined. Otherwise 3mm Top, Right, Bottom, Left.)
Paper Tray Capacity	20 Photo Sheets, 100 Sheets Standard
Media Handling	Печать на CD/DVD, Печать без полей, Automatic duplex (A4, plain paper), Художественная печать, Задний лоток для плотных носителей, Поддержка плотных носителей
GENERAL	
Product dimensions	523 mm x 379 mm x 169 mm (Width x Depth x Height)
Noise Level	5 B (A) with Epson Premium Glossy Photo Paper / Photo RPM mode - 37 dB (A) with Epson Premium Glossy Photo Paper / Photo RPM mode
Compatible Operating Systems	Mac OS X 10.6.8 or later, Windows 10 (32/64 bit), Windows 7 (32/64 bit), Windows 8 (32/64 bit), Windows 8.1 (32/64 bit), Windows Vista (32/64 bit), Windows XP Professional x64 Edition SP2 or later, Windows XP SP3 or later (32-bit), Windows Server 2003 SP2 or later
Included Software	Epson Photo+, Epson ScanSmart, EpsonNet Config
Mobile and Cloud Printing Services	Apple AirPrint, Mopria, Epson Smart Panel App, Epson Connect (Email Print, Remote Print Driver), Epson Connect (Email Print, Scan-to-Cloud)
OTHER FEATURES	
Panel	Type: Colour, Diagonal: 10.9
Memory Cards	MicroSD*, MicroSDHC*, MicroSDXC*, MiniSD*, SD, SDHC, SDXC, MiniSDHC*, Mini SDXC*
Features	Прямая печать с USB, Сенсорный экран, PictBridge , Прямая печать
OTHER	

LOGISTICS INFORMATION

EcoTank Photo L8180

WHAT'S IN THE BOX

- Main unit
- AC cable
- Driver and Utilities (CD)
- Ink set
- Quick Start Guide
- Гарантийные документы

INK COMPATIBILITY

- 115 EcoTank Cyan ink bottle
- 115 EcoTank Grey ink bottle
- 115 EcoTank Magenta ink bottle
- 115 EcoTank Photo Black ink bottle
- 115 EcoTank Pigment Black ink bottle

INK YIELD DATA

Included		
	* 1,800 photos	* 1,800 photos
Replacement		

* Quoted yields are extrapolated based on Epson original methodology from the print simulation of Test Patterns provided in ISO/IEC 24712 or 29103. Quoted yields are NOT based on ISO/IEC 24711 or 29102. Quoted yields may vary depending on the images that you are printing, the paper type that you are using, the frequency of your prints and environmental conditions such as temperature. During the initial printer setup, a certain amount of ink is used to fill the print head's nozzles, therefore the yield of the initial bundled set will be lower.

1) Указанные ресурсы фотоконтейнеров экстраполированы на основе шаблона ISO/IEC 29103 по методологии Epson при печати фотографий формата 10×15 см, и НЕ основаны на ISO/IEC 29102. Указанные ресурсы могут варьироваться в зависимости от печатаемых изображений, типа используемой бумаги, частоты печати и условий окружающей среды, например, температуры воздуха. Во время первоначальной настройки принтера часть чернил расходуется на заполнение дюз печатающей головки, поэтому ресурс стартового комплекта может быть ниже. Подробнее: www.epson.eu/pageyield. 2) Epson Smart Panel и Epson Connect требуют беспроводного подключения к интернету. Подробнее: www.epsonconnect.com.

EPSON®